

8x6 HEAVY DUTY SHED - ASSEMBLY INSTRUCTIONS



IMPORTANT :
ASSEMBLY OF THIS
SHED REQUIRES TWO
PEOPLE

ISSUE 0708

SHOULD YOU REQUIRE ANY ADDITIONAL GUIDANCE WITH THE ASSEMBLY OF YOUR SHED PLEASE CONTACT OUR TECHNICAL HELP LINE ON 0844 248 9853.

Thank you for choosing this garden building manufactured by the UK's largest manufacturer of timber garden products. In order to gain the most benefit from it, please note the following:
- Exercise particular care and follow instructions whilst cutting the roofing felt. If it is cut incorrectly, additional roofing felt can be inexpensively purchased from most good DIY retailers or garden centres.

- Most buildings are pre-treated with a factory base coat for protection during storage and transit. We recommend that you treat your new building as soon as possible after assembly, using a wood preservative treatment. Apply in accordance with the manufacturers instructions.


- If there are any technical queries with the product, please contact our customer help line on 0844 248 9853 between the hours of 8.30 am and 5.00 pm Monday to Friday.

- Please ensure that you thoroughly check all component parts for quantity and quality before you commence building the product. If there are any missing parts, please contact the help line as shown immediately. The manufacturer cannot be held liable for damaged items once any part of the product has been fitted or altered in any way (e.g. Painted)


- Timber is a natural material. It will shrink and swell as a result of varying moisture content.

- Please keep all plastic bags and small parts away from children in order to reduce the risk of suffocation.

REQUIRED TOOLS : (NOT SUPPLIED)




HDSHED86FP (FIXING PACK CONTENTS) :




PLEASE NOTE: ALL SCREWS AND NAILS SHOWN BELOW AND IN INSTRUCTIONS ARE TO SCALE TO ASSIST IN IDENTIFICATION OF REQUIRED FIXINGS.

Components Included :



HDSHED86FL Floor x 1



HDSHED86L (Loose Timber Items)

Timber Glazing Strips :
15120428DTR (15x12x428mm) qty 2
15120450DTR (15x12x450mm) qty 1
15120540DTR (15x12x540mm) qty 6

Timber Corner Strips :
24121600DTR (24x12x1600mm) qty 4


Timber Barge Boards :
71121145PARA1DTR (71x12x1145mm) qty 4

70120180FINDTR (Finials) qty 2


Other Loose Items

Pw610457 (Plastic Window 610x457mm) qty 2

85014 Felt x 1




1




Place pre-assembled HDSHED86FL (floor section) on to prepared site. Floor bearers run from front to back of building.

2




Position HDSHED86PE (plain end of shed) onto floor so that the left and right hand edges of the panel are flush with the edges of the floor. Place one of the HDSHED86WS or HDSHED86PS (side panel)s onto the floor and place up against HDSHED86PE (plain end panel). Secure side panel to end panel using 3 x 50mm screws placed as shown to left. **Do not secure the panels to the floor at this point.**

3




Using procedure outlined in step 2, position and secure the remaining HDSHED86WS or HDSHED86PS (side panel) and HDSHED86CF (door end) panel.

4




Once all four of the panels are in place and fastened together, secure them to the floor using 50mm screws. Each of the side panels require 3 screws and end panels require 2. It is vital that all screws are positioned so that they locate into floor bearers.

5




Offer SLS (opening window) up to central window opening. With window in open position, and ensuring that the window is centred in window opening, secure through the plate on the window hinge into the batten above the window opening with three 30mm screws per hinge.

6




Position window casement stay on bottom of opening window (inside shed) as shown to left. Secure stay with two 20mm screws. Position the two casement pins so that they line up with the first and last holes on the casement stay. Mark the position of the two pins and secure each pin in place with two 20mm screws.

7





With window in open position, place the 15120450DTR (15x12x450mm glazing strip) along the bottom of the central window opening on the outside of the shed. Glazing strip must be centred in window opening, and must butt up against rebated section of window sill. Secure glazing strip in place with three panel pins.

8




With window in fully closed position, place a 15120540DTR (15x12x540mm glazing strip) to the left and right hand sides of the window from inside shed. Glazing strips must butt up against window, and framework to left and right of window opening. Secure each glazing strip in place with three panel pins.

9



To glaze the two fixed windows, place a Pw610457 (styrene window) into each of the window openings from inside the shed. Place a 15120540DTR (15x12x540mm glazing strip) to the left and right hand side of each fixed window from inside the shed. Ensuring that they butt up against the window, secure each one to the vertical window framework with three panel pins. Place a 15120428DTR (15x12x428mm glazing strip) across the bottom of each fixed window on the outside of the shed and secure in place with three panel pins.

10




Prior to placing roof sections on shed, attach a "Z" bracket to each end of the two short battens on each HDSHED86RF (roof section) with a 30mm screw.

Place one of the HDSHED86RF (roof sections) on top of the shed. When in place, the roof section should overhang by equal amounts at either end of the shed and should be positioned so that when both roof sections are in place they meet at a point. Secure roof section in place with 30mm nails placed at 300mm intervals into framework of either end of and the side of the shed. Repeat this procedure for the remaining roof section.


Once both roof sections are in place secure them together on the inside of the shed with the provided ridge bracket. The bracket must be secured to the highest batten on each roof with a 30mm screw and should be positioned centrally between the door and plain end.

11





Open 85014 (roofing felt) and roll out flat on ground.


Cut the felt into three equal lengths. Place the first piece of felt on the roof so that it overlaps by equal amounts at either end of the shed, and by approximately 40mm at the eave side of the roof. Secure felt to roof with felt nails placed at 150mm intervals. Cut and fold felt at corners and secure fold with a felt nail repeat procedure for opposite Side of roof. Place the third piece of felt on the apex of the roof so that it overlaps equally at either end and either side of the roof. Secure felt to roof with felt nails placed at 150mm intervals along either side.



12





30mm




Attach a turn bottom to the top and bottom of the vertical door batten with a 30mm screw. Turn buttons must be positioned so that they hold door closed against framework of door end.

13





30mm





Attach pad bolt to short block on back of door with four 30mm screws. Attach pad bolt receiver to vertical batten on opposite door with two 30mm screws. Pad bolt and pad bolt receiver must be aligned as shown above.

14



Secure a 24121600DTR corner strip to each of the four corners with three 30mm nails per strip. Nails should be placed approximately as shown to left. Bottom of corner strip should be in line with bottom of cladding on side panels.

15



Position 71121145PARA1DTR (barge boards) on both ends of shed so that the top edge of the board is in line with the top edge of the roof and the point of the board meets up with the highest point of the roof. Secure each barge board in place with three 30mm nails placed as shown above. Trim off any excess felt that is showing below the barge boards. Once in place, attach a 70120180FINDTR (finial) over join of the barge boards with two 30mm nails.