



ASGARD 'VANGARD' PACK CONTENTS

ITEM NO	PART DESCRIPTION	QTY
1	38029 TOP PANEL 1542*949	1
2	37903 BASE PANEL 1494*899	1
3	36971 LH BACK PNL 746*1260	1
4	37015 RH BACK PNL 766*1260	1
5	38003 LH SIDE 904*1310	1
6	38004 RH SIDE 904*1310	1
7	38020 LH DOOR 675*1235	1
8	38028 RH DOOR 642*1235	1
9	38031 COVER PLATE 61*25	2
10	37222 DOOR STOP 256*56*35	1
11	CSK SCREW ZSCREW340	18
12	SELF TAPPER ZSCREW100	76
13	ANCHOR BOLT ZSCREW32	4
14	LEVELLERS 2,3 & 5mm	2ea
15	SEAL PLUGS ZCOMPPLAS02	4

SELF ASSEMBLY INSTRUCTIONS



**ASGARD
VANGARD**



PLEASE NOTE FOR SAFETY REASONS THE ASSEMBLY OF THIS UNIT **REQUIRES TWO PEOPLE.**

BASE INSTRUCTIONS

A FIRM, LEVEL, FLAT SURFACE IS REQUIRED AS A BASE FOR THIS UNIT SUCH AS CONCRETE OR FLAGS.

- MINIMUM BASE MEASUREMENT FOR VANGARD IS 1500*1000

TOOLS REQUIRED

- POSI-DRIV SCREWDRIVER
(POWER DRIVER RECOMMENDED)

- 6mm DIA MASONRY DRILL

- 13mm SOCKET SPANNER
(FOR ANCHOR FIXINGS)

- A TUBE OF ALL WEATHER SEALANT SUITABLE FOR STEEL AND CONCRETE.

DOOR ALIGNMENT & ANCHORING OF UNIT

IT IS IMPORTANT TO CORRECTLY LEVEL THE UNIT USING THE PACKING PIECES PROVIDED, ONCE ASSEMBLY IN ACCORDANCE WITH THE INSTRUCTIONS OVERLEAF IS COMPLETE AND PRIOR TO FIXING THE UNIT TO THE GROUND.

- SLIDE THE PACKING PIECES UNDER THE CORNERS OF THE UNITS BASE AS REQUIRED UNTIL AN EQUAL GAP HAS BEEN ACHIEVED AROUND THE DOORS ALLOWING FOR THEIR SMOOTH OPERATION.

- DRILL THROUGH THE FOUR HOLES IN THE BASE OF THE UNIT USING 6mm DIA MASONRY DRILL TO A DEPTH OF 70mm.

- SCREW IN THE ANCHOR FIXINGS. (THESE HAVE A SELF CUTTING THREAD)


IF NOT ANCHORING THE UNIT USE THE SELF SEAL PLUGS TO BLOCK THE FIXING HOLES (FIT FROM UNDERSIDE)


SEALING THE UNIT

- TO HELP PREVENT WATER INGRESS WE RECOMMEND THAT A THIN BEAD OF SEALANT IS USED ON THE BASE FRT JOINTS, AND ALSO A 10mm BEAD IS USED ALL AROUND THE UNIT TO FLOOR


PLEASE SEE OUR WEBSITE FOR DETAILS OF MAINTENANCE OF THIS PRODUCT
WWW.ASGARDSS.CO.UK


STEP 1




PARTS	INSTRUCTION
RH BACK - 4 BASE - 2	POSITION RH BACK '4' UP TO BASE PANEL '2' ENSURING HOLES ARE ALIGNED AND THAT THE BACK CENTRAL FOLD IS POSITIONED IN THE CUTOUT SLOT IN THE BASE. SCREW THE PANELS TOGETHER.
4* 	


STEP 2




PARTS	INSTRUCTION
RH SIDE - 6 COVER PLATE - 9	POSITION THE RH SIDE '6' UP TO THE PRE ASSEMBLED BACK AND BASE ENSURING ALL HOLES ARE ALIGNED, SCREW TOGETHER. ON THE FRONT TWO FIXING HOLES POSITION ONE COVER PLATE '9' IN THE CORNER, ALIGNING FIXING HOLES, SCREW IN POSITION. (THE COVER PLATE HIDES THE EXPOSED SCREW POINTS)
16* 	


STEP 3




PARTS	INSTRUCTION
LH BACK - 3	LOCATE LH BACK PANEL '3' INTO THE BASE AND RH BACK AS SHOWN ENSURING THAT IT SLOTS INTO THE CENTRAL BASE CUTOUT AND THAT THE CENTRAL VERTICAL FOLDS ARE CORRECTLY ALIGNED.
13* 	SCREW TOGETHER ALONG THE BASE AND VERTICAL JOINT.


STEP 4




PARTS	INSTRUCTION
LH SIDE - 5 COVER PLATE - 9	REPEAT STEP 2 WITH LH SIDE '5' AND THE REMAINING COVER PLATE '9'
16* 	


STEP 5




PARTS	INSTRUCTION
TOP - 1 DOOR STOP - 10	POSITION DOOR STOP '10' ON THE INSIDE OF THE FRONT OF THE TOP '1' AS SHOWN. ALIGN WITH THE 3 CENTRAL HOLES AND SCREW TOGETHER. THE LARGE CIRCULAR HOLES ALLOW ACCESS FOR THE FIXING SCREWS.
3* 	


STEP 6




PARTS	INSTRUCTION
TOP - 1 DOOR STOP - 10	POSITION THE PRE-ASSEMBLED TOP PANEL OVER THE CARCASE AS SHOWN ENSURING THAT THE ASGARD LABEL IS ON THE FRONT RH SIDE OF THE TOP CHECK HOLES FOR ALIGNMENT & SCREW IN POSITION.
SEALANT	TO HELP PREVENT WATER INGRESS WE RECOMMEND APPLYING A BEAD OF 'ALL WEATHER SEALANT' ON THE FRONT CORNER JOINTS AS SHOWN PRIOR TO FITTING THE DOORS.
18* 	

STEP 7



PARTS	INSTRUCTION
LH DOOR - 7 RH DOOR - 8	WE RECOMMEND THAT YOU USE HAND HELD DRIVERS RATHER THAN POWER DRIVERS WHEN FIXING THE DOORS. IT IS IMPORTANT TO SUPPORT THE DOORS AT ALL TIMES WHEN FITTING THE SCREWS TO ENSURE CORRECT ALIGNMENT AND SO NOT TO DAMAGE THE THREADED INSERTS.
18* 	ALIGN HINGES OF LH DOOR '7' (NON LOCKING) AND RH DOOR '8' (LOCKING) SCREW IN POSITION.

STEP 8



PARTS	INSTRUCTION
LEVELLERS - 14 SEALANT	HAVING FITTED THE DOORS IT MAY BE NECESSARY TO USE THE LEVELLING SHIMS '14' UNDER THE CORNERS OF THE UNIT IN ORDER TO ACHIEVE AN EVEN GAP AROUND THE DOORS AND ENABLE THEIR SMOOTH OPERATION. WE RECOMMEND APPLYING AN ADDITIONAL BEAD OF SEALANT ALL ROUND THE OUTER EDGE OF THE UNIT WHERE IT COMES INTO CONTACT WITH THE CONCRETE OR FLAGGED BASE.