


Thank you for purchasing your shed from Forest Garden. No matter what size garden, a shed is the most practical of garden structures. Simply follow these step by step instructions and our top tips and you'll be enjoying your shed for many years to come. If you have any questions or need advice, our friendly team is here to help.

# SHED INSTRUCTIONS


## PENT SHEDS (6x4, 7x5, 8x6, 10x6)

### FIXING PACK CONTAINS:


FIXING PACK CODE: MSFP2




3 x 16mm Screws QTY: 2  
Forest Badge QTY: 1



Flush Hinges  
QTY: 2



Hasp & Staple  
QTY: 1



Z-Brackets (45mm)  
QTY: 4

**Missing something or need more information?**  
Call our aftersales team on  
0333 321 3142

**Visit our website for spare instructions and more information**  
[www.forestgarden.co.uk](http://www.forestgarden.co.uk)


## BEFORE YOU START

Please read through these instructions to familiarise yourself with your shed. We recommend that you **check all the components** using the lists found on the front and back pages before you start to build.


All of our sheds are constructed in the same way. They simply come with different components depending on the type of shed you have. Don't worry if your fixing pack contains some spare items at the end of the build (you haven't missed a bit!) we have sent you a generic fixing pack to suit the shed range.

## BASE PREPARATION


It is vital that you build your new shed on a **solid, level base**. Timber or Plastic Shed Bases are ideal, as is solid concrete or concrete slabs.




**Timber Base**  
Self-constructed/  
Buy pre-made




**Concrete**  
Concrete surface/  
Concrete slabs



**Pro Shed Base**  
Interlocking  
eco-friendly base



**Broken Slabs/Gaps**  
Uneven slab sizes  
with no cement




**Soil**  
A base of soil or  
grass only

If you have an existing base and think it is suitable for your new shed to be sited on, it is important you check that it is level and does not deviate by any more than 15mm from edge to edge. If this is not the case the building will twist, causing gaps to appear in the sections and the roof, doors, and windows to misalign.


There is more information on base preparation on our website [www.forestgarden.co.uk](http://www.forestgarden.co.uk)

## TOOLS NEEDED

We recommend using the following tools (not supplied):




Tape Measure



Sharp Knife




Pozidrive  
Screwdriver




Drill & 2-6mm  
Drill Bits



Hammer



Ladder



Spirit Level

We recommend getting everything aligned properly before screwing together and that the **screw holes are pre-drilled** at this stage to **avoid splitting the timber**. We do not provide pre-drilled holes due to the nature of expanding and shrinking timber, which can cause pre-drilled holes to misalign.



**IMPORTANT**  
Assembly requires 2+  
adults.



**REMINDER**  
Always pre-drill before  
screwing.

PLEASE KEEP PLASTIC BAGS AND SMALL PARTS AWAY FROM CHILDREN  
CHECK AND TIGHTEN ALL THE FIXINGS APPLIED TO THIS PRODUCT ON A REGULAR BASIS

## CARE & ATTENTION

To help you get the most out of our products it is useful to know a little more about the properties of timber, what is normal and how your shed may behave as the seasons change. Wood is an extremely durable material for construction but as a natural product when used outdoors it is susceptible to changes in the environment.

### THINGS THAT YOU MIGHT SEE IN YOUR PRODUCT



#### MOVEMENT, TWISTING & WARPING

Wood contains a natural level of moisture so decreasing humidity levels in the surrounding air may cause panels to change their shape as the porous fibres shrink. This can be exaggerated during prolonged periods of dry weather. Movement and gaps in timber products are normal, in most cases the wood will revert to its original form once the high temperatures subside and there is more moisture content in the air. Similarly, in the winter months, the opposite may occur with wood swelling.



#### EXPANSION, CONTRACTION, SPLITS & CRACKS

All timber will expand and contract according to its environment. As a result of this expansion and contraction, it is very common to see splits and cracks developing in the wood. Splits are common during the spring and summer months as the wood begins to dry out. The outer surface dries first and contracts, contracting over a still expanded core of the wood. The result of this is that splits and cracks appear along the grain of wood. These splits are not a fault and do not affect the structural integrity of a product.



#### MOULD & BLUE STAIN

Mould is a surface-dwelling fungus that feeds on the nutrients and debris contained in the surface cells of timber. The most common problems associated with mould are discoloured timber and an increase in permeability of the timber. Blue stain is part of the same family but penetrates deeper into the surface layers of the timber. It stains the timber a dark blue, whereas mould is usually black. These do not cause the timber to rot. Keep the building well ventilated to avoid mould.

#### ADVICE ON FELT HANDLING & USAGE


Roofing felt is flexible at temperatures above 5°C. In cold temperatures extra care must be taken when handling and installing to prevent cracking and damage to the felt. The felt should not be rolled, folded, or used in temperatures lower than 5° C. In cold temperatures the felt should be stored above 10°C (indoors) for 24 hours prior to use. Felt must be lifted, not dragged, and should be stored on its end on a dry surface.

### 8 TOP TIPS TO ENSURE YOUR SHED IS FULLY WATERPROOF


- 1 POSITION YOUR SHED IN THE BEST LOCATION IN YOUR GARDEN**  
Avoid areas where water pools and which are constantly wet. Position away from trees and cut back any overhanging foliage which can cause moisture to be trapped against the walls and debris to collect on the roof.
- 2 RAISE YOUR SHED OFF THE GROUND**  
Ideally, any concrete base should be the same footprint as the shed to allow surface water to run off without pooling. A timber base can also be used. Raise your shed 50mm above ground level.
- 3 SEAL THE BEARERS**  
If using a wooden base, we recommend treating it with a treatment containing wax or oil. Also coat the bearers that meet the ground to prevent moisture rising.
- 4 USE AN END-GRAIN PROTECTOR**  
To protect the corners and panel joins, an end grain protector can be applied.
- 5 SEAL THE PANELS & WINDOWS**  
Use a flexible silicone sealant around windows to prevent water ingress. This can also be used where two sections of the shed join together. Apply internally.
- 6 CONSIDER ADDING GUTTERS**  
Adding guttering around the fascia of the shed will redirect rainwater away from the shed's foundation.
- 7 KEEP VENTILATED**  
Good airflow around the perimeter of the shed and regular ventilation inside the shed will help prevent mould and mildew.
- 8 CONSIDER A WATER SEALANT**  
You may want to consider painting your shed with a water sealant at least once a year. This will help reduce the risk of water ingress. We would recommend using 'Bostik Cementone Water Seal' of which can be purchased from multiple DIY stores.

## HEALTH & SAFETY


We strongly recommend that PPE (Personal Protective Equipment) is used throughout your build to ensure you are protected from any potential health and safety risks. **Do not exempt yourself from wearing PPE.**




Cut-Resistant  
Gloves




Protective Glasses



Protective Boots



Protective Mask



Working At  
Height

### THE ROOF OF THIS BUILDING IS NOT A LOAD BEARING STRUCTURE

The components provided may be heavy. Please lift with caution and with a minimum of 2 people. Please carefully unpack your shed and loose components as they may have moved during transportation.

## TREATMENT INFORMATION

The treatment applied to your shed is to ensure longevity and protection against fungal decay and rot. This may leave colour variations, but these will even out as the moisture content stabilises.

Dip Treatment	Pressure Treatment
Dip treatment is to provide protection against fungal decay	Pressure treatment is to provide protection against rot
Dip treated sheds <b>MUST</b> be re-treated every year	Pressure treated sheds <b>do not</b> need to be re-treated every year
10 year guarantee	25 year guarantee

Use the 'waterproofing top tips' to increase the longevity of your shed.  
See our website for more information at [www.forestgarden.co.uk /guide-to-our-products/](http://www.forestgarden.co.uk/guide-to-our-products/)

**Treated timber contains biocidal products for control of wood destroying organisms.**

**Active Ingredients** - Propiconazole, Tebuconazole, IPBC, Permethrin, Benzyl-C12-16-Alkyldimethyl Chlorides. (Dip Treated Sheds)

Basic Copper Carbonate, DDA Carbonate, DDA Chloride. (Pressure Treated Sheds)

- Wear gloves when handling.
- Avoid inhalation of sawdust.
- Do not use in contact with drinking water or food.
- Do not use for animal bedding or in fish ponds.
- Dispose of treated wood responsibly.

## DISCLAIMER

**Check you have all your parts prior to assembly.**

Timber is a natural material of which will shrink and swell because of varying moisture content.

Assembly of damaged parts may be deemed to be acceptance, and this may affect the remedies you are entitled to.

If the product is not constructed in accordance with the instructions, or is altered in anyway (e.g. painted), the manufacturer cannot be held liable for any resulting damage.

If you are organising a third party to install your shed, it is best not to schedule this immediately on receipt of your order, to give you time to check your delivery.




# IDENTIFY YOUR SHED

From the floor plans below, identify your shed based on the **width, depth and shed code** provided. You will need this to identify the side panel positions before assembling your shed. Use the key as a guide.

Assembly of your chosen shed will slightly differ throughout the steps based on the size of your shed. This will be mentioned throughout the instructions for guidance.

## KEY




- (A)— 2ft Panel (590 x 1603mm)
- (B)— 2ft Panel (590 x 1945mm)
- (C)— 3ft Panel (885 x 1603mm)
- (D)— 3ft Panel (885 x 1717mm)
- (E)— 3ft Panel (885 x 1945mm)  
(With & without windows)
- (F)— 4ft Panel (1180 x 1603mm)
- (G)— 4ft Panel (1180 x 1717mm)
- (H)— 4ft Panel (1180 x 1945mm)  
(With & without windows)
- (I)— 3ft Door Panel (885 x 1945mm)
- (J)— 4ft Door Panel (1180 x 1945mm)

### PLEASE NOTE

The sheds are made up of multiple sections where same size panels are interchangeable.

### SINGLE DOOR

The door is flexible for all shed types and can be hinged onto either side.



# 1 CONSTRUCTION




## 1a FLOORS & SIDES



Position the floor in your desired location. The 6x4 shed will only have one floor. For the 7x5, 8x6 and 10x6 sheds, butt the adjoining bearers together. 7x5, 8x6 and 10x6 will have two floors. Use the floor plans as a guide for your floor positions.

Layout the panels around your shed base.

We recommend to start in a back corner then work from the back panels to the front panels for assembly.




## 1b

Start at a back corner. See the section layout on page 5 to confirm position. Secure the corner as shown below.


Repeat the process for remaining panels and secure panels together. Make sure that the bottom frame of the wall panel rests on the outer edge of the floor.

Secure the panels into place by screwing into the floor. Screw into the door frame in the door panel into the floor to keep secure.


EG. INSIDE CORNER



EG. SIDES




EG. INTO FLOOR



## 1c


Attach the Triangular Pent Section by screwing to the wall panel. Also screw from the front panel into the Triangular Pent Section to keep it more secure as shown below. Repeat for the other Triangular Pent Section.






PRE-DRILL  
WITH 2MM BIT  
FOR ALL STEPS  
BELOW.

**Secure windows** by screwing through the window cover strips and window into the panel frame (30mm screws). Screw into the top and bottom of the window and into the interior sill to keep secure (25mm screws). Make sure the window is centralised for all window frames as shown below.



### WINDOW POSITIONING



## COVER AND DOOR STRIPS






PRE-DRILL  
WITH 2MM BIT  
FOR ALL STEPS  
BELOW.

Attach the cover strips onto the corners. Ensuring they are flush to the bottom edge of the panels as shown below.

Attach the cover strips onto the adjoining panels. Ensuring it is flush to the bottom edge of the panels as shown below.

Secure the door weather strip onto the side you want the hinges, and ensure it's flush to the floor and against the face of the wall panel framing.

Attach the slamming strip onto the opposite side you want the hinges, onto the wall panel shown below.



### PLEASE NOTE

Screwing the door weather strip onto the wall panel determines the side of your hinges.

## ROOF




PRE-DRILL  
WITH 2MM BIT  
FOR ALL STEPS  
BELOW.

Attach the Z-brackets with screws onto the top face at each end of the beam(s).

For the 6x4 and 7x5 sheds, you will have only one beam. Screw the Z-brackets to the centre of the front and back panels (measurements shown below). Ensure the Z-brackets are facing the right way as shown below.

For the 8x6 and 10x6 sheds, you will have two beams. Use the measurements below to space them across the front and back panels and screw as shown below. Ensure the Z-brackets are facing the right way as shown below.




# 4b

Place the OSB roof sheets, one at a time onto the shed frame and beams. Ensure where the OSB roof sheets join, are central for each beams.

Before screwing the OSB roof sheets onto the roof, screw the roof support strips to the OSB roof sheets. Ensure they are flush to the edges. Repeat this for both sides. The measurements shown below are to show the orientation of the sheets. The strip(s) will be the same length as the 2 edges when joined together as shown below.


Once the roof support strips are screwed onto the front and back of the OSB roof sheets, push the sheets forward from the back, ensuring the roof support strip is in contact with the shed as shown below. Then screw the OSB roof sheets into the beam(s) and shed frame.

# 8




6X4 & 7X5 SHEDS

30MM SCREWS




8X6 & 10X6 SHEDS

30MM SCREWS




6X4 & 7X5 SHEDS

30MM SCREWS



8X6 & 10X6 SHEDS

30MM SCREWS



**TOP TIP:** Mark onto the OSB sheet and draw a line to ensure you drill and screw into the beam(s).

# 4c


For the 6x4 and 7x5 sheds, screw the shorter roof support strips central onto the sheets. For the 8x6 and 10x6 sheds, screw the shorter roof support strips into the space provided as shown below. Repeat this for both sides and ensure they are flush to the sheet edges.

Measure out equal lengths based on your chosen shed and overlap it on the top, around the edges and fold the corners; tack to keep secure as shown below. Ensure 50mm at the bottom and work from the bottom to the top.

Secure the fascias with screws as shown below. The fascia options differ based on your chosen shed. The parts that are left over are an indication on which steps to follow. Use pages 8-9 for measurement guidance.


6X4 & 7X5 SHEDS

30MM SCREWS




8X6 & 10X6 SHEDS

30MM SCREWS




**TOP TIP:** Use measuring tape to measure out equal lengths & cut with a sharp knife. Hammer the tacks into the felt. Add the tacks at 150mm intervals.


6X4 & 7X5 SHEDS




8X6 & 10X6 SHEDS



40MM SCREWS



40MM SCREWS



# 5

## DOOR FIXINGS




Attach 2 hinges onto the door frame with the measurements provided. Please take note of the hinge position shown below.

Place the door into the opening, ensuring it's level. Make sure the hinges are up against the door weather strip face.

Fix the Hasp and Staple as shown. Ensure the screws go into the framework behind.


HINGE POSITION

25MM SCREWS



Allow a 5mm gap at the top when placing door.


25MM SCREWS



HASP & STAPLE POSITIONING

**TOP TIP:** Line up the hasp & staple. Mark the edges with a pencil for guidance.

25MM SCREWS



FRAMEWORK

Make sure the outer face of the notch on the hinge is in line with the door face.





## PRESSURE TREATED OVERLAP PENT SHEDS

### CHECK YOU HAVE ALL YOUR PARTS PRIOR TO ASSEMBLY.

Overlap Pent 6' x 4' - No Windows (OPP64NWM)		
Part Code	Description	Qty
OPPMRHA4	Right Pent Section (370x1180mm)	1
OPPMLHA4	Left Pent Section (370x1180mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPM885TTP	Section E - 3ft Pent Front Panel (885 x 1945mm)	1
OPM885TDP	Section I - 3ft Door Panel (885 x 1945mm)	1
OPM1180PP	Section F - 4ft Panel (1180 x 1603mm)	2
MSPDR	Door (582x1692mm)	1
MSBFL46	Floor (1180x1826mm)	1
28121637PPT	Slamming Strip (28x12x1637mm)	1
28280973	Roof Support Strip (28x28x973mm)	2
28281934	Roof Support Strip (28x28x1934mm)	2
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161925PT	Cover Strip (44x16x1925mm)	3
45451153PAI179	Roof Beam (45x45x1153mm)	1
59121390PPT	Side Fascia (59x12x1390mm)	2
59121978PPT	Front Fascia (59x12x1978mm)	1
OSB13759678	OSB Roof Sheet (1375x967x8mm)	2

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 6' x 4' - 2 Windows (OPP64M)		
Part Code	Description	Qty
OPPMRHA4	Right Pent Section (370x1180mm)	1
OPPMLHA4	Left Pent Section (370x1180mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPM885TWP	Section E - 3ft Pent Front Window Panel (885 x 1945mm)	1
OPM885TDP	Section I - 3ft Door Panel (885 x 1945mm)	1
OPM1180PP	Section F - 4ft Panel (1180 x 1603mm)	2
MSPDR	Door (582x1692mm)	1
MSBFL46	Floor (1180x1826mm)	1
28121637PPT	Slamming Strip (28x12x1637mm)	1
28160550PT	Window Cover Strip (28x16x550mm)	3
28280973	Roof Support Strip (28x28x973mm)	2
28281934	Roof Support Strip (28x28x1934mm)	2
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161925PT	Cover Strip (44x16x1925mm)	3
45451153PAI179	Roof Beam (45x45x1153mm)	1
59121390PPT	Side Fascia (59x12x1390mm)	2
59121978PPT	Front Fascia (59x12x1978mm)	1
RPET885	Window (428x577mm)	2
OSB13759678	OSB Roof Sheet (1375x967x8mm)	2

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 7' x 5' - No Windows (OPP75NWM)		
Part Code	Description	Qty
OPPMRHA5	Right Pent Section (368x1475mm)	1
OPPMLHA5	Left Pent Section (368x1475mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	1
OPPM1180BP	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1
OPM885TDP	Section I - 3ft Door Panel (885 x 1945mm)	1
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	2
OPM590PP	Section A - 2ft Panel (590 x 1603mm)	2
OPM1180TTP	Section H - 4ft Pent Front Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL257	Floor (737x2121mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28281115	Roof Support Strip (28x28x1115mm)	6
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451441PAI181	Roof Beam (45x45x1441mm)	1
59121132PPT	Front Fascia (59x12x1132mm)	2
59121688PPT	Side Fascia (59x12x1688mm)	2
OSB168811158	OSB Roof Sheet (1688x1115x8mm)	2

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 7' x 5' - 2 Windows (OPP75M)		
Part Code	Description	Qty
OPPMRHA5	Right Pent Section (368x1475mm)	1
OPPMLHA5	Left Pent Section (368x1475mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	1
OPPM1180BP	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1
OPM885TDP	Section I - 3ft Door Panel (885 x 1945mm)	1
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	2
OPM590PP	Section A - 2ft Panel (590 x 1603mm)	2
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL257	Floor (737x2121mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28160550PT	Window Cover Strip (28x16x550mm)	3
28281115	Roof Support Strip (28x28x1115mm)	6
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451441PAI181	Roof Beam (45x45x1441mm)	1
59121132PPT	Front Fascia (59x12x1132mm)	2
59121688PPT	Side Fascia (59x12x1688mm)	2
RPET590	Window (575x577mm)	2
OSB168811158	OSB Roof Sheet (1688x1115x8mm)	2

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 8' x 6' - No Windows (OPP86NWM)		
Part Code	Description	Qty
OPPMRHA6	Right Pent Section (362x1770mm)	1
OPPMLHA6	Left Pent Section (362x1770mm)	1
OPPM1180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	2
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	4
OPM1180TTP	Section H - 4ft Pent Front Panel (1180 x 1945mm)	1
OPM1180TDP	Section J - 4ft Door Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL46	Floor (1180x1826mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28280988	Roof Support Strip (28x28x988mm)	4
28281242	Roof Support Strip (28x28x1242mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451783PAI183	Roof Beam (45x45x1783mm)	2
59121020PPT	Side Fascia (59x12x1020mm)	2
59121259PPT	Front Fascia (59x12x1259mm)	4
OSB20328288	OSB Roof Sheet (2032x828x8mm)	3

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 8' x 6' - 2 Windows (OPP86M)		
Part Code	Description	Qty
OPPMRHA6	Right Pent Section (362x1770mm)	1
OPPMLHA6	Left Pent Section (362x1770mm)	1
OPPM1180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	2
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	4
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
OPM1180TDP	Section J - 4ft Door Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL46	Floor (1180x1826mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28160550PT	Window Cover Strip (28x16x550mm)	3
28280988	Roof Support Strip (28x28x988mm)	4
28281242	Roof Support Strip (28x28x1242mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	3
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	3
45451783PAI183	Roof Beam (45x45x1783mm)	2
59121020PPT	Side Fascia (59x12x1020mm)	4
59121259PPT	Front Fascia (59x12x1259mm)	2
RPET590	Window (575x577mm)	2
OSB20328288	OSB Roof Sheet (2032x828x8mm)	3

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 10' x 6' - No Windows (OPP106NWM)		
Part Code	Description	Qty
OPPMRHA6	Right Pent Section (362x1770mm)	1
OPPMLHA6	Left Pent Section (362x1770mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPPM1180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	4
OPM885TTP	Section E - 3ft Pent Front Panel (885 x 1945mm)	2
OPM1180TDP	Section J - 4ft Door Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL56	Floor (1475x1826mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28280988	Roof Support Strip (28x28x988mm)	4
28281537	Roof Support Strip (28x28x1537mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	4
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	4
45451783PAI183	Roof Beam (45x45x1783mm)	2
59121020PPT	Side Fascia (59x12x1020mm)	4
59121555PPT	Front Fascia (59x12x1555mm)	2
OSB203210258	OSB Roof Sheet (2032x1025x8mm)	3

Contact our aftersales team with your product code if you are missing your felt.

Overlap Pent 10' x 6' - 2 Windows (OPP106M)		
Part Code	Description	Qty
OPPMRHA6	Right Pent Section (362x1770mm)	1
OPPMLHA6	Left Pent Section (362x1770mm)	1
OPPM885BP	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
OPPM1180BP	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1
OPM885PP	Section C - 3ft Panel (885 x 1603mm)	4
OPM590TTP	Section B - 2ft Pent Front Panel (590 x 1945mm)	1
OPM1180TWP	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
OPM1180TDP	Section J - 4ft Door Panel (1180 x 1945mm)	1
MSPDR	Door (582x1692mm)	1
MSBFL56	Floor (1475x1826mm)	2
28121637PPT	Slamming Strip (28x12x1637mm)	1
28160550PT	Window Cover Strip (28x16x550mm)	3
28280988	Roof Support Strip (28x28x988mm)	4
28281537	Roof Support Strip (28x28x1537mm)	4
38121710PPT	Weather Strip (38x12x1710mm)	1
44161695PT	Cover Strip (44x16x1695mm)	4
44161810PT	Cover Strip (44x16x1810mm)	2
44161925PT	Cover Strip (44x16x1925mm)	4
45451783PAI183	Roof Beam (45x45x1783mm)	2
59121020PPT	Side Fascia (59x12x1020mm)	4
59121555PPT	Front Fascia (59x12x1555mm)	2
RPET590	Window (575x577mm)	2
OSB203210258	OSB Roof Sheet (2032x1025x8mm)	3

Contact our aftersales team with your product code if you are missing your felt.

(The parts do not have codes on them. They are listed above should you need to order one.)

# DIP TREATED SHIPLAP PENT SHEDS

## CHECK YOU HAVE ALL YOUR PARTS PRIOR TO ASSEMBLY.

Shiplap Pent 6' x 4' - No Windows (SDP64NWM)		
Part Code	Description	Qty
<b>SDPMRHA4</b>	Right Pent Section (358x1180mm)	1
<b>SDPMLHA4</b>	Left Pent Section (358x1180mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
<b>SDM885TTP</b>	Section E - 3ft Pent Front Panel (885 x 1945mm)	1
<b>SDM885TDP</b>	Section I - 3ft Door Panel (885 x 1945mm)	1
<b>SDM1180PP</b>	Section F - 4ft Panel (1180 x 1603mm)	2
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL46</b>	Floor (1180x1826mm)	1
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28280973</b>	Roof Support Strip (28x28x973mm)	2
<b>28281934</b>	Roof Support Strip (28x28x1934mm)	2
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451153PAII79</b>	Roof Beam (45x45x1153mm)	1
<b>59121390PDT</b>	Side Fascia (59x12x1390mm)	2
<b>59121978PDT</b>	Front Fascia (59x12x1978mm)	1
<b>OSB13759678</b>	OSB Roof Sheet (1375x967x8mm)	2
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 6' x 4' - 2 Windows (SDP64M)		
Part Code	Description	Qty
<b>SDPMRHA4</b>	Right Pent Section (358x1180mm)	1
<b>SDPMLHA4</b>	Left Pent Section (358x1180mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
<b>SDM885TWP</b>	Section E - 3ft Pent Front Window Panel (885 x 1945mm)	1
<b>SDM885TDP</b>	3ft Pent Door Panel (885 x 1945mm)	1
<b>SDM1180PP</b>	Section F - 4ft Panel (1180 x 1603mm)	2
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL46</b>	Floor (1180x1826mm)	1
<b>28120550PDT</b>	Window Cover Strip (28x12x550mm)	3
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28280973</b>	Roof Support Strip (28x28x973mm)	2
<b>28281934</b>	Roof Support Strip (28x28x1934mm)	2
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451153PAII79</b>	Roof Beam (45x45x1153mm)	1
<b>59121390PDT</b>	Side Fascia (59x12x1390mm)	2
<b>59121978PDT</b>	Front Fascia (59x12x1978mm)	1
<b>RPET885</b>	Window (428x577mm)	2
<b>OSB13759678</b>	OSB Roof Sheet (1375x967x8mm)	2
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 7' x 5' - No Windows (SDP75NWM)		
Part Code	Description	Qty
<b>SDPMRHA5</b>	Right Pent Section (356x1475mm)	1
<b>SDPMLHA5</b>	Left Pent Section (356x1475mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	1
<b>SDPM1180BP</b>	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1
<b>SDM885TDP</b>	Section I - 3ft Door Panel (885 x 1945mm)	1
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	2
<b>SDM590PP</b>	Section A - 2ft Panel (590 x 1603mm)	2
<b>SDM1180TTP</b>	Section H - 4ft Pent Front Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL257</b>	Floor (737x2121mm)	2
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28281115</b>	Roof Support Strip (28x28x1115mm)	6
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451441PAII81</b>	Roof Beam (45x45x1441mm)	1
<b>59121132PDT</b>	Front Fascia (59x12x1132mm)	2
<b>59121688PDT</b>	Side Fascia (59x12x1688mm)	2
<b>OSB168811158</b>	OSB Roof Sheet (1688x1115x8mm)	2
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 7' x 5' - 2 Windows (SDP75M)		
Part Code	Description	Qty
<b>SDPMRHA5</b>	Right Pent Section (356x1475mm)	1
<b>SDPMLHA5</b>	Left Pent Section (356x1475mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	1
<b>SDPM1180BP</b>	Section G - 3ft Pent Back Panel (1180 x 1717mm)	1
<b>SDM885TDP</b>	3ft Door Panel (885 x 1945mm)	1
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	2
<b>SDM590PP</b>	Section A - 2ft Panel (590 x 1603mm)	2
<b>SDM1180TWP</b>	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL257</b>	Floor (737x2121mm)	2
<b>28120550PDT</b>	Window Cover Strip (28x12x550mm)	3
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28281115</b>	Roof Support Strip (28x28x1115mm)	6
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451441PAII81</b>	Roof Beam (45x45x1441mm)	1
<b>59121132PDT</b>	Front Fascia (59x12x1132mm)	2
<b>59121688PDT</b>	Side Fascia (59x12x1688mm)	2
<b>RPET590</b>	Window (575x577mm)	2
<b>OSB168811158</b>	OSB Roof Sheet (1688x1115x8mm)	2
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 8' x 6' - No Windows (SDP86NWM)		
Part Code	Description	Qty
<b>SDPMRHA6</b>	Right Pent Section (350x1770mm)	1
<b>SDPMLHA6</b>	Left Pent Section (350x1770mm)	1
<b>SDPM1180BP</b>	Section G - 4ft Pent Back Panel (1180 x 1717mm)	2
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	4
<b>SDM1180TTP</b>	Section H - 4ft Pent Front Panel (1180 x 1945mm)	1
<b>SDM1180TDP</b>	Section J - 4ft Door Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL46</b>	Floor (1180x1826mm)	2
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28280988</b>	Roof Support Strip (28x28x988mm)	4
<b>28281242</b>	Roof Support Strip (28x28x1242mm)	4
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451783PAII83</b>	Roof Beam (45x45x1783mm)	2
<b>59121020PDT</b>	Side Fascia (59x12x1020mm)	4
<b>59121259PDT</b>	Front Fascia (59x12x1259mm)	2
<b>OSB20328288</b>	OSB Roof Sheet (2032x828x8mm)	3
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 8' x 6' - 2 Windows (SDP86M)		
Part Code	Description	Qty
<b>SDPMRHA6</b>	Right Pent Section (350x1770mm)	1
<b>SDPMLHA6</b>	Left Pent Section (350x1770mm)	1
<b>SDPM1180BP</b>	Section G - 4ft Pent Back Panel (1180 x 1717mm)	2
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	4
<b>SDM1180TWP</b>	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
<b>SDM1180TDP</b>	4ft Door Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL46</b>	Floor (1180x1826mm)	2
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28120550PDT</b>	Window Cover Strip (28x12x550mm)	3
<b>28280988</b>	Roof Support Strip (28x28x988mm)	4
<b>28281242</b>	Roof Support Strip (28x28x1242mm)	4
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	3
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	3
<b>45451783PAII83</b>	Roof Beam (45x45x1783mm)	2
<b>59121020PDT</b>	Side Fascia (59x12x1020mm)	4
<b>59121259PDT</b>	Front Fascia (59x12x1259mm)	2
<b>RPET590</b>	Window (575x577mm)	2
<b>OSB20328288</b>	OSB Roof Sheet (2032x828x8mm)	3
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 10' x 6' - No Windows (SDP106NWM)		
Part Code	Description	Qty
<b>SDPMRHA6</b>	Right Pent Section (350x1770mm)	1
<b>SDPMLHA6</b>	Left Pent Section (350x1770mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
<b>SDPM1180BP</b>	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	4
<b>SDM885TTP</b>	Section E - 3ft Pent Front Panel (885 x 1945mm)	2
<b>SDM1180TDP</b>	Section J - 4ft Door Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL56</b>	Floor (1475x1826mm)	2
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28280988</b>	Roof Support Strip (28x28x988mm)	4
<b>28281537</b>	Roof Support Strip (28x28x1537mm)	4
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	4
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	4
<b>45451783PAII83</b>	Roof Beam (45x45x1783mm)	2
<b>59121020PDT</b>	Side Fascia (59x12x1020mm)	4
<b>59121555PDT</b>	Front Fascia (59x12x1555mm)	2
<b>OSB203210258</b>	OSB Roof Sheet (2032x1025x8mm)	3
Contact our after-sales team with your product code if you are missing your felt.		

Shiplap Pent 10' x 6' - 2 Windows (SDP106M)		
Part Code	Description	Qty
<b>SDPMRHA6</b>	Right Pent Section (350x1770mm)	1
<b>SDPMLHA6</b>	Left Pent Section (350x1770mm)	1
<b>SDPM885BP</b>	Section D - 3ft Pent Back Panel (885 x 1717mm)	2
<b>SDPM1180BP</b>	Section G - 4ft Pent Back Panel (1180 x 1717mm)	1
<b>SDM885PP</b>	Section C - 3ft Panel (885 x 1603mm)	4
<b>SDM590TTP</b>	Section B - 2ft Pent Front Panel (590 x 1945mm)	1
<b>SDM1180TWP</b>	Section H - 4ft Pent Front Window Panel (1180 x 1945mm)	1
<b>SDM1180TDP</b>	Section J - 4ft Door Panel (1180 x 1945mm)	1
<b>MSDDR</b>	Door (582x1692mm)	1
<b>MSBFL56</b>	Floor (1475x1826mm)	2
<b>28121637PDT</b>	Slamming Strip (28x12x1637mm)	1
<b>28120550PDT</b>	Window Cover Strip (28x12x550mm)	3
<b>28280988</b>	Roof Support Strip (28x28x988mm)	4
<b>28281537</b>	Roof Support Strip (28x28x1537mm)	4
<b>38121710PDT</b>	Weather Strip (38x12x1710mm)	1
<b>40121695PDT</b>	Cover Strip (40x12x1695mm)	4
<b>40121810PDT</b>	Cover Strip (40x12x1810mm)	2
<b>40121925PDT</b>	Cover Strip (40x12x1925mm)	4
<b>45451783PAII83</b>	Roof Beam (45x45x1783mm)	2
<b>59121020PDT</b>	Side Fascia (59x12x1020mm)	4
<b>59121555PDT</b>	Front Fascia (59x12x1555mm)	2
<b>RPET590</b>	Window (575x577mm)	2
<b>OSB203210258</b>	OSB Roof Sheet (2032x1025x8mm)	3
Contact our after-sales team with your product code if you are missing your felt.		

(The parts do not have codes on them. They are listed above should you need to order one.)